


# User-driven design of child restraint information

Julie Brown



# Background

## Optimal crash protection




# Background



# Background


## Optimal crash protection





# Background

## Incorrect use of child restraints


- is widespread and long standing
- increases risk of serious injury by up to 3 times



Errors in  
installation  
& Use




# Background




Integrated model of behaviour (Fishbein)

# Background



Integrated model of behaviour (Fishbein)

# Background



Integrated model of behaviour (Fishbein)



## Background change for correct use

### **Skills**

- Need to know how to use the restraint correctly

### **Environment**

- Physical barriers to achieving correct use

# Informative materials



Labels on the restraint

Instruction booklets



## Maxi Guard PRO Line

### Britax Safe-n-Sound Maxi Guard PRO™



View the product page for Britax Safe-n-Sound Maxi Guard PRO™

### DOWNLOADS

[Maxi Guard and PRO - Manual.pdf](#)

### INSTRUCTIONAL VIDEOS

[Maxi Guard PRO™ Installation Video](#)

(Manufactured from 4/1/2016 - Present) Where do I find the manufacture date?

Instructional videos

# Informative materials

## **Instructions provided with child restraint**

- regulated by product standards
- historically not involved users in development

# Health communication


Gold standard for health communication is to involve consumers in the development of informative materials




Jay E, Aslani P, Raynor DK. User testing of consumer medicine information in Australia. *Health Education Journal*. 2010

**Sless D. Usable medicines information. Communication Research Institute of Australia p-Paper, Hawker. 2001**

# User-driven design of informative materials



# New user-developed instructions



<http://q-r.to/baoUit>



Lab-based user-tested instructions, QR coded video and swing tags



## New user-developed instructions




**Britax MaxiGuard Pro  
forward facing car seat up to 8 years**




**Britax Compaq convertible rearward-  
forward facing car seat up to 4 years**



# User-driven design of informative materials



# Method - Lab trial



## New user-developed instructions



**Britax MaxiGuard Pro  
forward facing car seat up to 8 years**



**Britax Compaq convertible rearward-  
forward facing car seat up to 4 years**

# Method - Lab trial



## TASK

Using the instructions provided:

- Install CRS in forward facing mode (from rear facing mode) following the instructions available to them
- Secure the mannequin in the CRS
  - No time limit
  - Do the best job you can
  - Researcher will not answer questions

# Data collected

## CORRECT USE SCORESHEET

**20 items** – including

- harness fit,
- belt routing and adjustment,
- top tether tension & anchor point,
- slack and twists in straps

Assessment of **any errors** & **serious errors** - based on crash lab tests done in previous studies

## COMPREHENSION

**10 items** relevant to correct installation - including:

- what to check and how,
  - correct belt paths,
  - shoulder height guides
- 
- Locating information in materials (/10)
  - Use that information to answer the question (/10)



# Outcome measures

## Primary Outcome

Overall serious misuse Yes/No


**serious misuse** = More than one minor error/ one or more serious errors  
 -serious error defined from previous crash test studies  
 -multiple minor errors equate to similar performance as a serious errors.

Error	Description	Effect
1		Serious/
2		Minor
3		
4		
20		

Example Error Scoring Checklist



# Serious error classification



Tai, Bilston & Brown ESV, 2011

# Outcome measures

## Primary Outcome

### Overall serious misuse Yes/No

**serious misuse** = More than one minor error/ one or more serious errors

- serious error defined from previous crash test studies
- multiple minor errors equate to similar performance as a serious errors.


## Secondary Outcomes

### %Overall comprehension

- Locating information in materials
- Use that information to answer the question

### % Errors


- 20 item check list






# Results

27% MORE CORRECT USE WITH NEW MATERIALS



# Results


## SIGNIFICANT INCREASE IN OMPREHENSION



$p < 0.001$


# Results

**ALMOST 10% REDUCTION IN THE OVERALL NUMBER OF ERRORS**



p=0.056

# Results



# Results

## **SUMMARY**

- User-driven materials increase correct use by 27%
- User-driven materials increased comprehension by 42%
- Significant linear relationship between increased comprehension and reduction in errors

## **IMPLICATIONS**


- Increasing the comprehension of instructions may be effective measure to counter misuse
- Improving instructions may be a cost-effective and far reaching intervention to reduce misuse
- User-driven design can increase comprehension and reduce serious errors in use

# Limitations

- **Laboratory setting**
- **Immediate assessment**
- **Researcher present**
- **Dummy-child and not a real journey**
- **Participants included many non-parents**

**NEED FOR A TRIAL UNDER REAL WORLD CONDITIONS**

# Background



Integrated model of behaviour (Fishbein)



# NeuRA

*Discover. Conquer. Cure.*

## INJURY PREVENTION

**Co-authors:**

**Alex Hall**, Catherine Ho, Bianca Albanese, Lisa Keay, Kate Hunter, Jude Charlton, Lynne Bilston, Andrew Hayen,

**Program collaborators:**

Jake Olivier, Sjanne Koppel, Jane Elkington, Raman Sran

**Funding:**

New South Wales Centre for Road Safety;  
National Health and Medical Research Council




[neura.edu.au](http://neura.edu.au)





# User-driven design of informative materials



# Results

27% MORE CORRECT USE WITH NEW MATERIALS

